Lakewood Expanding Roll Sizer

LAKEWOOD PROCESS MACHINERY



How our 'EXR' Sizer Works:

Product is conveyed onto the EXR bed. The unique rotation of the rollers singulates the product for accurate sizing. As product moves down the sizer bed, the distance between the rollers expands, allowing product to fall through to the exit conveyors. The sized product can then be conveyed either to the right or to the left to the next processing station.





EXR Sizer Features:

- *Hand crank size adjustments made independent of one another to allow you to change the size of your product on each conveyor without affecting the sizes on adjacent conveyors*
- *Sizing range of 1/4" to 6"*
- *Anywhere from 2 to 10 exit conveyors to accomodate the number of size categories desired for your product or to fit your product flow requirements.*