

CLAMSHELL WHEEL DENESTERS

A SIMPLE, TIME TESTED DESIGN, GEARED TOWARDS DENESTING PINTS

Wheel Denester

- **All stainless steel construction**
- **Precision machined denester wheels**

Clamshells are placed onto the rear loading section of the wheel denester where they are staged until a hopper eye (included with denester) which is mounted onto the hopper feeding your clamshells, recognizes berries in the hopper. As the hopper eye recognizes berries, it will automatically start the denesting process to ensure very little product is spilled, and will keep moving clamshells under the hopper at all times, assuming the hopper is being fed at a steady rate.

The key to our Wheel Denester is the precision machined wheels which separate the cups from one another. For each rotation of the denester wheel, a clamshell will gently fall onto the filler's container conveyor.

* Wheel Denester Capacities

Model	Capacity (Pints per Minute)
Single Lane	200+ Pints per minute
Dual Lane	400+ Pints per minute

** Wheel denester capacities of 200+ containers are based on running pint containers - capacities for larger or different sized clamshells may vary.*

Wheel Denester Options

Mounting Options
Stand Alone (includes stand for denester)
Mountable (mounts directly onto filler)
LH / RH Models
LH Model (Standard)
RH Model (Required only for RH filler)

